

Arpeggiator Button

Enable/disable MIDI note arpeggiator.

Press and hold edit button to randomize arp playback.

Hold Button

Enable/disable MIDI and arpeggiator note hold.

Press and hold edit button to enable/disable arpeggiator transpose mode.

Octave Buttons

Shift MIDI note octave up or down.

See manual for secondary functions.

Edit Button

Press and hold to enable secondary button functions

Clock Button


Tap tempo or external clock divider.

Press and hold edit button first to set the clock source. Internal, MIDI, external gate.

Filter Mode Button

Press to select filter response. Lowpass, bandpass, and highpass.

Press and hold edit button first to set the LFO range.



3.5mm TRS MIDI Adapter Input Jack

Oscillator Seed Buttons

Press to select oscillator seed wave.
Press and hold edit button first to enable/disable midi pitch control.

Patch Points:

White Text = Output

Green Text = Input

Dynamics Mode Button

Press to select dynamics mode. VCA, lowpass gate, and lowpass gate pluck.

Press and hold edit button first to enable/disable midi gate control.

Visit pittsburghmodular.com for complete Taiga manual and customer support.